

PINOUT INFORMATION FOR 30 PIN CONNECTOR (CONT.)

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
16	17	18	19	20	21	22	23	24	25	26	27	28	29	30

115 Volt AC Model

24 Volt AC Model

GAMING AND LOTTERY PINOUTS ONLY!

- | | | |
|----------|-----------------------------|------------------------|
| • Pin 1 | CREDIT RELAY, Common | Same |
| • Pin 2 | RESERVED | CREDIT RELAY N.O. |
| • Pin 3 | RESERVED | 24 VAC HOT (Power) |
| • Pin 4 | 115 VAC NEUTRAL (Power) | RESERVED |
| • Pin 5 | RESERVED | KEY |
| • Pin 6 | KEY | RESERVED |
| • Pin 7 | CREDIT PULSE | Same |
| • Pin 8 | INTERRUPT_NOT | Same |
| • Pin 9 | SERIAL / PULSE_NOT | Same |
| • Pin 10 | LOW LEVEL GND / SIGNAL GND | Same |
| • Pin 11 | SERIAL_DATA_OUT / | |
| | BDS_MASTER_RXD | Same |
| • Pin 12 | NOT USED | Same |
| • Pin 13 | NOT USED | Same |
| • Pin 14 | NOT USED | SERIAL_DATA_IN |
| • Pin 15 | NOT USED | Same |
| • Pin 16 | CREDIT RELAY, Normally Open | DC RET./CSH.CNTER.LOW |
| • Pin 17 | RESERVED | RESERVED |
| • Pin 18 | RESERVED | RESERVED |
| • Pin 19 | KEY | |
| • Pin 20 | 115 VAC HOT (Power) | 24 VAC NEUTRAL (Power) |
| • Pin 21 | EARTH GROUND | KEY |
| • Pin 22 | OUT-OF-SERVICE_NOT | Same |
| • Pin 23 | RESERVED | RESERVED |
| • Pin 24 | ACCEPT_ENABLE_NOT | Same |
| • Pin 25 | 200 OHMS TO 5 VOLT | Same |
| • Pin 26 | SEND_NOT | Same WITH |
| | | BDS_MASTER_TXD |
| • Pin 27 | RESERVED | Same |
| • Pin 28 | RESERVED | Same |
| • Pin 29 | RESERVED | Same |
| • Pin 30 | RESERVED | Same |

Insert this end first

USE #2 Pencil
Photocopy can
be used

Complete sections
1-5 ONLY

7

Of Bill
Directions

1 2 4

1

\$1
\$2
\$5
\$10
\$20

High
Accept

High
Security OFF

2

Pulse

Short Long Credit Line
Vending Only

3

Pulses per
dollar

1 2 3 4

4

Interface
Selection

Vending Gaming
Always
Enable Gaming

5

6

**Model 2600
Configuration
Coupon 001**

250056078 Rev. G3