

PINOUT INFORMATION FOR 30 PIN CONNECTOR (CONT.)

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
16	17	18	19	20	21	22	23	24	25	26	27	28	29	30

115 Volt AC Model

24 Volt AC Model

GAMING AND LOTTERY PINOUTS ONLY!

• Pin 1	CREDIT RELAY, Common	Same
• Pin 2	RESERVED	CREDIT RELAY N.O.
• Pin 3	RESERVED	24 VAC HOT (Power)
• Pin 4	115 VAC NEUTRAL (Power)	RESERVED
• Pin 5	RESERVED	KEY
• Pin 6	KEY	RESERVED
• Pin 7	CREDIT PULSE	Same
• Pin 8	INTERRUPT_NOT	Same
• Pin 9	SERIAL / PULSE_NOT	Same
• Pin 10	LOW LEVEL GND / SIGNAL GND	Same
• Pin 11	SERIAL_DATA_OUT / BDS_MASTER_RXD	Same
• Pin 12	NOT USED	Same
• Pin 13	NOT USED	Same
• Pin 14	NOT USED	SERIAL_DATA_IN
• Pin 15	NOT USED	Same
• Pin 16	CREDIT RELAY, Normally Open	DC RET./CSH.CNTER.LOW
• Pin 17	RESERVED	RESERVED
• Pin 18	RESERVED	RESERVED
• Pin 19	KEY	
• Pin 20	115 VAC HOT (Power)	24 VAC NEUTRAL (Power)
• Pin 21	EARTH GROUND	KEY
• Pin 22	OUT-OF-SERVICE_NOT	Same
• Pin 23	RESERVED	RESERVED
• Pin 24	ACCEPT ENABLE_NOT	Same
• Pin 25	200 OHMS TO 5 VOLT	Same
• Pin 26	SEND_NOT	Same WITH BDS_MASTER_TXD
• Pin 27	RESERVED	Same
• Pin 28	RESERVED	Same
• Pin 29	RESERVED	Same
• Pin 30	RESERVED	Same

Insert this end first

USE #2 Pencil
Photocopy can
be used

Complete sections
1 - 5 ONLY

\$1

High Accept High Security OFF

7

\$2

\$5

\$10

\$20

\$50

\$100

3

Pulses per Dollar

Interface Selection

4

Vending Gaming Always Enable Gaming

5

6

mei

Model 2800
Configuration
Coupon 001