
## Single Stacker Comb Installation Instructions Kit #100-0099

- 1. Turn off power to machine.
- 2. Unplug and remove Single Stacker.
- 3. Remove #6-32 rail screws in front on both left and right side.
- 4. Place Stacker Comb in aligning holes with the holes from the two screw holes.
- 5. Replace the two #6-32 screws making sure to screw them into the rails.
- 6. Replace Single Stacker and plug in.
- 7. Turn on power to machine.



Document #101-0145 9/13/04